


## Brief Specification

### Function

1. ON/OFF
2. Current display
3. Riding mode selection
4. Speed display
5. KM/H & MPH
6. Backlight indicator
7. 6KM/H work
8. PAS level selection
9. Error code indicator
10. SET operation
11. Distance indicator
12. Trip time indicator
13. Battery indicator
14. Mobile phone charging indicator
15. Cable definition
16. Auto sleep after 5 minutes
17. Error code definition

### Full view area



#### 1. ON/OFF

C500B is off, Click "φ", open the display. And hold "φ" for 3s, the display is off again.

#### 2. Current Display



Each mark is 2A.

#### 3. Riding mode selection

- POWER ☒
- NORMAL ☒
- ECO ☒

#### 4. Speed display



#### 5. KM/H & MPH

Press UP or DOWN to select KM/H or MPH in SET4.

#### 6. Backlight indicator

Press "φ" to turn on the backlight.



#### 7. 6KM/H work

6KM Hold DOWN, it will get in 6KM/H work.

#### 8. PAS level selection



Press UP or DOWN to change the PAS level.

#### 9. Error code indicator



It will show the error code when system has problem.

#### 10. SET operation

Hold SET for 2s and enter into setting interface.



Set 0: Riding mode selection.

Set 1: Press DOWN to reset the trip distance.

Set 2: Max speed limited setting.

Set 3: Wheel diameter setting.

Set 4: KM/H & MPH.

※ Press UP or DOWN to select parameter, Keep press SET for 1 second to save and exit.

#### 11. Distance indicator



to GO need to be customized.

#### 12. Trip time indicator



#### 13. Battery indicator



The percentage of battery capacity and charge discharge times option need to be customized.


#### 14. Mobile phone charging indicator



Press UP and SET for 2s and the USB icon can be lighted.

---

## 15. Cable definition



- 1 Red: Battery+
- 2 Blue: Lock
- 3 Black: Battery-
- 4 Green: UART-RECEIVE (RXD)
- 5 White: UART- SEND (TXD)

## 16. Auto sleep after 5mins

When speed keeping at 0 for 5mins, it will go to sleep automatically.

## 17. Error code definition

- 【0】 normal
- 【1】 current error
- 【2】 throttle error
- 【3】 motor no phase position
- 【4】 Hall error
- 【5】 Brake error
- 【6】 Under voltage
- 【7】 Motor stalling
- 【8】 communication controller receiving error
- 【9】 communication display receiving error

**Note:** In this product instructions, the “UP” represents “+” and the “DOWN” represents “-”.